

Product-Information

Stonecleaner S1

Properties: For cleaning stone with a high silicate content such as granite, clinker, sandstone a.s.o.

Chem. condition: highly acidic, however hydrofluoroicacid-free, frost-resistant

Dosage . 1:1 up to 1:20 diluted with water according to the toughness of stain

Directions for use : apply Heidt & Schwarzfeld Stonecleaner S1 only on previously wetted surfaces. Stonecleaner S1 is to be used generally pure with Nylon brush or Nylon paint brush. Preferably work in upward movements onto areas not greater than 5 m² at a time. Keep below lying surfaces wet. Let it react for 5 -10 min. Then, if possible use water to polish up with a high-pressure machine or a steamjetmachine until the water used for washing reaches pH-Neutral.

In order to impregnate we afterwards recommend you to use our Imprägnat 290s

Application : according to the toughness of stain

Note: Do not use Stonecleaner S1 into direct sunlight. Protect any metal parts, aluminium, zinc, alloy steel, any glass surfaces, sheet glass, plastic glass, steamy glass panes and autoglass, as well as plastics and plants. Avoid mixing with other detergents and chemicals.

Please follow carefully the instructions and safety recommendations out of the EU-safety regulation form.

Specifications : Expiration : minimum of 2 years

pH-value : ~1

Contents : non-ionic tenside, mineral acids, PH-stabilizers complexing fluorides, parfum oil and preservatives
drainage-safe (biodegradable according to DIN)

Container size : 20 L / container

UN-Number : 1789
UN-Number : 12670001
Item-Number : 10001

The product information is based upon research in labs and is the result of our experiences. Still they are only seen as unofficial. The information does not replace a pre-test in any individual case although such a pre-test is indispensable for the above use on each particular product. We decline all responsibilities as far as concerning the above translation.

Heidt & Schwarzfeld GmbH – Lochhamer Schlag 5 – 82166 Gräfelfing – Tel. 089/854 19 77 – 78 – Fax 089/85 55 04