

Product-Information

HS-Enzyme cleaner

ceilings, wall, carpet and upholstered furniture cleaner

Properties: HS- enzyme cleaner is a special system for cleaning strong stained ceilings, walls, carpets, and upholstered furniture. Fats, oils, nicotine, proteins, starch, sugar-compounds and some organic and anorganic dirt particles are decomposed and removed because of its co-ordinate activated enzyme. Moreover, by porous grounds, no need to wipe off, dry up a.s.o.

HS-Enzyme cleaner is effective on almost all grounds. HS-Enzyme is therefore particularly suitable for mineral fiber plates (acoustic ceilings), which cannot be cleaned in another way. According to the type of stain, the reaction time of the enzyme can last up to 12 hours.

Directions for use:

Dosage: 1 can of enzyme solution and 2 bottles of activator produce the finished solution. Shake very well. After diluting do not close the can.

Before the application: Hoover any stubborn dust. We recommend to cover furniture and floors, although there is no risk of staining and damaging the furnitures, if the product is properly used. Do not spray onto coated-glass surfaces. Important. Please use protective glasses and wrap your hair.

Processing: From a distance of approx. 20 cm spray very slightly on to the surfaces, which have to be cleaned. Use a sprayer preferably a spray gun. Important: Do not use a high-pressure cleaning equipment.

By porous surfaces no additional cleaning. By smooth surfaces leave the product to react approx. 2 minutes then with a viscous sponge or mop rub down.

Caution: keep the sponge always clean and slightly humid. Use several sponges. Duo-bucket system: separate dirty water and clean water. We advise you to work in team (2 persons) as followed:

Person A sprays first

- Person B wipes off

-Person A washes off with sponges

In case of strong stubborn stains do repeat again the above application

Application: 1 liter diluted solution for approx. 25m² surface (according to the toughness of stain)

Please turn the page

Note: Rinse immediately with abundant water.

Please follow carefully the instructions and safety recommendations out of the EU regulation form.

Expiration: The diluted solution expires within 10 days. After this time the product is no more efficient. Keep non used undiluted solution in an uncovered container. Please make sure that the rooms are enough ventilated.

undiluted solution expires within 2 years. Store in a cool dark place. Do not place in the sun.

Specifications:	pH-value	Enzyme solution 12,6 in activator 4,0 in , 10% solution 7,1
	Contents	enzyme concentrate 2 differents active surface active substance and salt
		activator hydrogen peroxyde<20%
	drainage-safe	(biodegradable according to DIN)

Barrel size: 1 carton contains
- 1 can with 5 ltr enzyme solution
- 2 bottles a 500 ml activator
(produces 6 liter solution ready for use)

UN-Number:	missing
UBA-Number:	12670040 enzyme solution
UBA-Number:	12670045 activator
Item-Number:	11000

The product information is based upon research in labs and is the result of our experiences. Still they are only seen as unofficial. The information does not replace a pre-test in any individual case although such a pre-test is indispensable for the above use on each particular product. We are not responsible for any incorrect translation.

Heidt & Schwarzfeld GmbH – Lochhamer Schlag 5 – 82166 Gräfelfing – Tel. 089/854 19 77 – 78 – Fax 089/85 55 04